



PILKINGTON

NSG Group Flat Glass Business

Technical Information

ATS-189
2010/05/27

Handling, Inspecting, Fabricating & Glazing Pilkington Eclipse™ Gold

SUMMARY

Pilkington recommends the following handling, inspecting, and fabricating guidelines for Pilkington **Eclipse™** Gold Glass. Although individual fabricating conditions may vary, the guidelines in this bulletin offer an excellent starting point for optimizing typical operations.

Pilkington **Eclipse™** Gold Glass is a gold color, pyrolytic coating on clear glass. The coating has been optimized for its gold appearance in outdoor reflection when glazed on #2 surface. It can be glazed monolithically, or incorporated into an insulating glass (IG) unit, with the reflective coating on the #2 (room side) surface of the outer light. It was not designed for use on the #1 surface where normal window dust and dirt would be more obvious than on non-coated glass. But the coating is sufficiently durable for #1 surface applications as it meets the European standard EN 1096-2 for exposed coatings.

Pilkington **Eclipse™** Gold coating does not have any low emissivity properties but can be combined with Pilkington **Energy Advantage™** Low-E in an (IG) unit for improved solar control and thermal insulation.

When laminated the coating should normally not be touching the pvb interlayer to preserve its published solar/optical performance values. When in contact with pvb the visible and solar transmission will increase, and the reflectivity will decrease.

Pilkington **Eclipse™** Gold Glass can be used in spandrel panels. Applying ceramic frits to the reflective coating would significantly change the visible reflective properties so the optimum spandrel design will have IG with the Pilkington **Eclipse™** Gold coating on #2 surface and a ceramic frit or silicone based opacifier on #4 surface.

GLASS HANDLING

Pilkington **Eclipse™** Gold Glass should be cut, washed, and generally processed with the reflective coated surface facing up. Note heat treatment (see below) can be with the coating down against clean rollers if needed for ceramic frit application to the glass surface.

INSPECTION

It is the responsibility of the fabricator to carefully inspect Pilkington **Eclipse™** Gold Glass, both before and after washing, as well as before any further fabrication. Glass not rejected by the fabricator during inspection prior to fabrication will be considered acceptable by Pilkington.

Pilkington **Eclipse™** Gold glass should be inspected in *transmitted* and *reflected* light, both from the reflective coated and the glass side of the lite.

When inspected in *transmitted* light, there should be a bright, uniform, diffused light (similar to an overcast sky) behind the glass. The objects which are seen in reflection (walls, ceilings, etc.) on the viewing side of the coated glass should be dark color or matte black and should have low level illumination on them to minimize masking reflections.

When inspected in *reflected* light the glass should be placed in front of a uniform, dark background to minimize transmitted images and the reflected image of a uniform diffuse light source or brightly illuminated white wall or screen (similar to an overcast sky) should be visible to the inspector.

Coated glass should also be inspected with a portable, bright spot light to simulate sunlight. This lighting can show marks, washing machine streaks, or finger prints which would otherwise not be visible in diffuse inspection lighting.

UNPACKING

Pilkington **Eclipse™** Gold glass is shipped in either standard cases, end caps or stoces. Like other Pilkington glass products, the glass surfaces are protected with a powdered interleaving material that resists moisture staining and abrasions between the individual lights.

Pilkington **Eclipse™** Gold Glass should never be removed from cases by “end opening” the case since sliding glass surfaces past each other may damage the coating or the glass surface.

Pilkington **Eclipse™** Gold Glass can be handled with suction cups. The cups must be clean and dry to prevent damage to or marking of the reflective surface. The cups should not be slid across the reflective surface.

SURFACE DETECTION

The coating does not conduct electricity and so standard low-e detectors should not be used. As the coating is on clear glass the normal double image reflection of a point touching the glass-side surface can be readily used for coated surface identification.

CUTTING

Stock Sheets

The fabricator is responsible for cutting stock sheets to eliminate imperfections from the finished cut piece.

Best results will be obtained by laying out the desired pattern in the middle of the stock sheet and making trim cuts on all 4 edges. Standard procedures used in cutting ¼" (6 mm) float glass should be practiced. All stock sheet edges must be trimmed a minimum of 1" (25 mm) to obtain a clean-cut edge. Special care should be exercised in cutting to avoid sliding metal tools (tape measures, etc.) over the reflective surface.

Pilkington **Eclipse™** Gold Glass should be cut with the coated side up to eliminate coating damage that could result from glass particles on the cutting table.

Cutting oils should be light, evaporating lubricants, such as "Low Odor Base Solvent" No. 529-66 available from Ashland Chemical, Charlotte, NC, phone: 800 522 1409. Keep the quantity of cutting oil to a minimum to reduce contamination of gloves and to allow easier washing the coated surface.

WASHING

Pilkington **Eclipse™** Gold Glass has a hard pyrolytic reflective coating. As with any coated product, care should be taken while washing the glass to prevent damage to the coating. The following recommendations are for washing reflective glass:

Mechanical Washing

Pilkington **Eclipse™** Gold Glass should be washed, with the coating side up, in a rotating cylindrical brush flat glass washing and drying machine. Pilkington recommends using a detergent solution of hot 50-60°C (120-140°F) clean water and a commercial detergent designed for glass washing. The final rinsing should be with clean, de-ionized water heated to at least 43°C (110°F). As with all washing machines, either the water should

be changed on a routine basis or a continuous overflow system should be used. Drying air should be filtered and controlled in such a manner so as not to leave water droplets on the glass surfaces.

Polypropylene brush rolls are recommended for glass washing machines. Brushes must be properly adjusted to avoid the possibility of reflective surface damage. When selecting the proper brush for washing Pilkington **Eclipse™** Gold Glass, consider that polypropylene brushes usually have a lower coefficient of friction, and are softer, and more flexible than nylon. Brush height settings should be such that only the bristle tips, rather than the sides of the bristles, sweep uniformly across the glass surface.

Never allow the glass to remain stationary under the rotating brushes.

It is recommended that a test light be run through the washer before starting production. The glass should then be inspected as detailed above.

Hand Washing

Pilkington **Eclipse™** Gold Glass can be cleaned and maintained by hand washing with non-abrasive cleaners. For hand washing Pilkington **Eclipse™** Gold Glass, a mild detergent and water solution is recommended. Uniformly apply the solution to the glass and wash with a clean, soft cloth, sponge, or pad. Rinse thoroughly with clean water and wipe or squeegee dry immediately. Make sure no metal parts of the cleaning equipment touch the reflective glass surface, and that no abrasive particles are trapped between the glass and the cleaning materials. Do not use HF (Hydrofluoric) or other acids, harsh chemical cleaners, abrasives, steel wool, or razor blades on the **Eclipse™** Gold reflective surface.

LAMINATING

Pilkington **Eclipse™** Gold Glass can be laminated. However, laminating with the gold coated surface towards the plastic interlayer will result in a small but noticeable reduction in reflectivity, an increase in transmission and a small change in reflected color. These changes will adversely change the solar/optical properties. It is recommended that each laminator conduct in-house adhesion tests, prior to actual production, to determine if an adequate bond to the coating has been obtained.

HEAT TREATMENT

Heating

Pilkington **Eclipse™** Gold Glass can be heat-strengthened, fully tempered or bent, after it is cut to size. Please refer to ATS Bulletin #177 for bending details. Pilkington recommends that Pilkington **Eclipse™** Gold Glass be properly cleaned and dried prior to heat-treating. The glass should be visibly clean at this stage to eliminate hand prints, fingerprints or other marks, which could be burnt into the surface during heat-treating.

The reflective coating can be facing up or down when heat-treating in a horizontal furnace. If the furnace rollers are clean, and no skidding or slippage occurs, the glass can be processed with the coating down against the rollers.

Pilkington **Eclipse**TM Gold Glass has an emittance of 0.84, the same as glass. This coated 6 mm glass only has 19% solar absorption and so it should be heat treated with furnace settings initially similar to those used for the same thickness of clear glass, which has 16% solar absorption.

Individual furnaces will have different heating characteristics, depending on their Infra Red peak wavelength and other factors, so some adjustments may be needed.

The first piece of tempered reflected glass processed should be examined for break pattern and distortion immediately after it has cooled down. Remember, the rate of feeding cold glass (individually or in continuous batches) into a hot furnace will have more effect on the glass temperature reached in the heating cycle than the presence or absence of the Pilkington **Eclipse**TM Gold coating.

Quenching

The forced convection heat loss during the quench is generally not affected by the presence of the coating, but normal air flow adjustments may be required to prevent bowing and to obtain an acceptable break pattern.

Optical distortions such as bow, warp, ripple, or roller wave are inherent in all heat-treated glass products. Reflective glass accentuates these distortions. Care must be taken not to overheat Pilkington **Eclipse**TM Gold Glass. Overheating Pilkington **Eclipse**TM Gold will cause excessive visible distortion and could damage the reflective coating. If excessive distortion or coating damage is experienced, a cooler glass temperature during the heat-treating process will be required. This is best achieved by shortening the furnace cycle time rather than changing top and bottom furnace temperature settings. Note that at no time should the glass temperature exceed 670°C (1240°F).

Sample lights of Pilkington **Eclipse**TM Gold Glass should be tested to ensure compliance with applicable safety standards and inspected for distortion prior to starting production. Confirmation that Pilkington **Eclipse**TM Gold Glass will meet or exceed all applicable safety glazing standards is the responsibility of the fabricator.

Note that heat-treated (tempered or heat strengthened) glass can often show a soft dappled shadow pattern from the furnace quench air when viewed in polarized light (see ATS #157 for details). Higher daylight transmitting glasses with reflective coatings will show this phenomenon more readily.

OPACIFICATION

Water based spray silicone materials, in a wide variety of colors, can be used on the Pilkington **Eclipse™** Gold coating as opacifiers. Samples must be viewed for visible change of coating reflectivity and color. As with all construction products, the material supplier should be asked to supply adequate proof of long term durability.

Applying ceramic frits to the reflective coating would significantly change the visible reflective properties so the optimum spandrel design will have IG with the Pilkington **Eclipse™** Gold coating on #2 surface and a ceramic frit or silicone based opacifier on #4 surface.

Pilkington **Eclipse™** Gold reflective glass can have fluorine free ceramic frits or enamels applied to the glass side or the reflective coated side. A test piece should be run with the desired frit to ensure satisfactory results. The glass can be successfully processed with the coating facing down provided the furnace rollers are clean and there is no sliding or skidding of the glass on the rollers due to excessively rapid speed changes or reversals, or speed miss-matches between roller sections.

SPANDREL GLASS

Pilkington recommends that, in general, glass be heat-treated when used in spandrel applications. Pilkington recommends that for optimum uniformity between vision and spandrel glass, Pilkington **Eclipse™** Gold spandrels be fabricated by constructing an insulating glass (IG) unit similar to the vision unit, with the reflective coating on the same surface (typically #2) as the vision units, and with a dark grey color ceramic opacifier applied to the #4 surface of the IG unit.

Using heat-treated insulating glass with ceramic enamel on the #4 surface (room-side) will eliminate read-through, minimize banding effects, and ensure a stable spandrel design. In order to withstand the high temperatures in spandrel panels the insulating glass secondary sealant used should be silicone and meet a high performance standard such as IGCC Level "A". See: ATS Bulletin #124.

Pilkington acknowledges that a number of factors make it impossible to achieve complete uniformity between vision and spandrel glass areas. See mock-up recommendations below.

INSULATING GLASS

When Pilkington **Eclipse™** Gold Glass is used on the second surface of insulating glass units no edge deletion of the reflective coating is required. Test results to date indicate that **Gold Eclipse** reflective glass is compatible with typical IG P.I.B., polysulfide, urethane and silicone sealants. The fabricator of Pilkington **Eclipse™** Gold Glass has the ultimate responsibility of testing to ensure that the proper sealant

is used for each application. Specific questions concerning compatibility should be directed to, and confirmed with, the individual sealant manufacturers.

STRUCTURAL SEALANT GLAZING

Structural sealant glazing allows for a clean, unobstructed, exterior building appearance when compared to traditional glazing methods which capture the glass edges in a frame. Because Pilkington **Eclipse™** Gold glass has higher daylight transmittance, some “read through” of the insulating glass sealant, spacer and the structural seal may be visible under certain lighting conditions when structural sealant glazing systems are used.

GLAZING CONSIDERATIONS

Pilkington **Eclipse™** Gold products were not designed for use in #1 surface installations. The coating has a less gold color in reflection when viewed from the coated side. With #1 surface glazing normal window dust and dirt would be more obvious than on non-coated glass, but the coating is sufficiently durable for #1 surface applications as it meets the European standard EN 1096-2 for exposed coatings. It is generally preferable to glaze Pilkington **Eclipse™** Gold products with the coating on the #2 surface.

Pilkington **Eclipse™** Gold has a higher solar reflection and a lower solar absorption than many competitive glasses, therefore, Pilkington **Eclipse™** Gold can usually be annealed glass when single or double glazed, and the glass is properly glazed with clean-cut and undamaged edges. (See ATS #139 or the Thermal Stress Calculator on www.pilkington.com/na for thermal stress analysis),

MOCK-UP CONSTRUCTION

The construction of a full-scale mock-up is recommended, where the glass can be examined, from both sides, in transmission and reflection. A full-size mock-up, including both vision and spandrel glass, should be constructed and viewed on site, representing the proposed building location and viewing geometry, and should be approved prior to final glass product selection and production. This will show the final installed appearance of the glass far better than viewing small hand held samples under interior lighting conditions.

Pilkington Gold Eclipse Glass REFLECTIVE COATING QUALITY SPECIFICATIONS

Uniformity

When viewed in reflection or transmission, as described above, from a distance of 10 feet (3 m), the coating will not have objectionable, bands, streaks or color differences as detailed in ASTM C 1376-03. "Specification for...Coatings on Glass".

Pinholes

There shall be no single visible spots on the coating greater than 3/32" (2.4 mm) diameter in the outer area, or greater than 1/16" (1.6 mm) dia. in the central area.

Scratches

There shall be no more than 2 readily apparent blemishes in a 3" (75 mm) dia. circle, or no more than 5 in a 12" (300 mm) dia. circle.

Quality Standard of Base Glass

The base glass shall meet the requirements for "glazing select" quality in the ASTM C 1036-05.

Optical Properties of Pilkington Eclipse™ Gold Glass

Optical properties may be found in the current edition of the Pilkington Product Brochure and on our website at www.pilkington.com/NA

Contact Pilkington North America, Inc. Architectural Technical Services, tel: 419 247 4448 for further information.

The information contained in this bulletin is offered for assistance in the application of Pilkington North America Inc. flat glass products, but **IT DOES NOT CONSTITUTE A WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.** Actual performance may vary in particular applications.